



Factory Shield Installation Instructions

Please read all instructions thoroughly before installation. Failure to follow all installation instructions will void any warranty implied or otherwise. FMF Racing is not responsible for problems due to improper installation and/or improper use.

Before you begin installing this product, we recommend wearing safety glasses.

Parts Supplied

(1) Factory Shield:	842820 or 842821
(1) clamp	901031
(1) reinforcement band	941103

Tools Required

#T27 Torx wrench flat-blade screwdriver
--

Note

While not necessary, we recommend removing the muffler from the vehicle for easier installation.

Installation

1. Locate the 2 outer screws and reinforcement band on the front end cap where your riding boot would come into contact with the muffler. Remove and save screws for later use.
2. Line up the new Factory Shield to match the contour of the front section of the muffler.
3. Open the supplied clamp completely to slide the small end through the slots on the backside of the Factory Shield.
4. Position the mounting holes in the Factory Shield to line up with the holes for the screws removed in step 1.
5. Align the supplied reinforcement band over the Factory Shield then insert the screws removed in step 1. Do not fully tighten at this time.
6. Position the head of the clamp at the top or back of the muffler and thread the ends of the clamp together. Do not fully tighten at this time.
7. Inspect the alignment of the Factory Shield with the muffler. Tighten the muffler screws only 1/4 turn after seating against the reinforcement band. Do not overtighten - the threads can strip out.
8. Tighten the Factory Shield clamp only until snug. Inspect regularly after riding to ensure clamp is tight.